RR-2644X4

SPECIFICATION

Features

Host Adapter Architecture

- → PCI-Express x4
- → 1External Mini-SAS port
- → Up to 4 SAS/SATA Hard Drives
- NCQ (Native Command Queuing)
- → Low Profile

Advance RAID Features

- → Support RAID 0,1,5,10 and JBOD
- Multiple RAID support
- Multiple logical drive support
- BIOS booting support
- Online Array roaming
- Automatic drive (insert / remove) detection
- Automatic RAID rebuild
- * 64bit LBA support greater than 2TB per volume
- → S.M.A.R.T (Early Warning System)
- TerabyteGuard for data protection and reliability
- Bad sector repair and remapping to reduce dropped
- → drives

Array Monitors, Alerts and Indicators

- * Hard Drive LED Indicators (Activity and Failed)
- Email Notification
- Alarm/Buzzer alerts for drive/array failure
- * Enclosure Management support with I2C and SGPIO

RAID Management

- Online Capacity Expansion (OCE)
- Online RAID Level Migration (OLRM)
- Quick and Background initialization for instant RAID configuration
- Write Back and Write Through support
- → API library for customization
- → CLI (Command Line Interface)
- Web GUI RAID management (local and remote monitoring)
- → SHI (Drive analysis driven from S.M.A.R.T)



Operating System Support

- →Microsoft® Windows® 2008/2003/XP/ 2000/x64 Edition/Vista 32 and 64 bit
- Linux (Fedora Core, Red Hat Enterprise/ CentOS, SuSE)
- → Mac OS X 10.4.x and above
- → FreeBSD
- → Linux Open Source

Package Contents

- → Controller Card
- → User's Guide
- Software CD with Drivers and Manual
- → Low profile bracket

Operating Voltage

→ PCI-e: 3.3V / Power: 5W



Prime Source Technologies Pvt. Ltd. Web site: www.primesource.in